

3D Simulation of Quantum Dot Devices

CROSSLIGHT
Software Inc.

Copyright 2005-6 Crosslight Software Inc.
www.crosslight.com


Physical Models

- **Quantum dot structure offers delta-like density of states that facilitates population inversion → Better emitters.**
- **Better temperature stability and lower threshold are expected.**
- **Modeling is separated into two parts (1) microscopic model that solves all the quantum states in a dot; (2) macroscopic model that uses (1).**

Microscopic Model


- **3D structure of QDOT as set up with Layer3D/GeoEditor3D.**
- **Use of rectangle coordinates for QDOT shapes of boxes and pyramids, etc.**
- **Use of cylindrical coordinates for QDOT of columnar or cone shapes.**
- **Schrodinger equation is discretized in 3D and solved with sparse eigen matrix techniques.**
- **Strain effects are taken into account by using strain dependent potential profiles and anisotropic effective masses for different band valleys (HH,LH,CH, etc.)**
- **Applicable for wurtzite structure (GaN-based) as well as for zincblende structure.**

A simple QDOT of a box



Use only $\frac{1}{2}$ of the symmetric structure

Quantum wave function of a box



File Name : box.sid_0001

File Type : LASTIP

Variable Name :

Wave_Intensity 1

3D Cube Contour Parameters :

X Range : 0 - 0.015

Y Range : 0 - 0.1


Z Range : 0 - 0.03

X Cut Line Num : 40


Y Cut Line Num : 40

Z Cut Line Num : 40

Wave_Intensity 1




Coupled columnar dots



Remark: It is a simplified structure. Real structure Of QDOT may have composition grading from InGaAs To InAs at the center of the dot.

Results for columnar dots




File Name : cone.std_0001
File Type : LASTIP


Variable Name :
Wave_Intensity 1

3D Cube Contour Parameters :
X Range : 0 - 0.012
Y Range : 0 - 0.043
Z Range : 0 - 0

X Cut Line Num : 40
Y Cut Line Num : 40
Z Cut Line Num : 40




Columnar dots (contours)




Macroscopic Model

- **Set up 2D/3D larger laser diode/LED/PD structure as usual.**
- **Import quantum levels and optical transition overlaps from microscopic solutions. If necessary, correct potential profile at the dot model.**
- **Use of delta-like density of states for optical gain, spontaneous emission and carrier concentration calculation.**
- **Use wetting layer as a reference to compute optical confinement and carrier sheet concentration for the dots.**


Band diagrams



Comparing PL with experiment




M. Sugawara, et. al.,
IEEE J. Select. Topics in
Quant. Electron. vol. 6,p462
2000.



Both QW and QDOT models are needed here.

Spectrum without broadening







Same conditions as previous Pages.

Temperature dependence study


- **Objective: to compare performance of MQW and QDOT lasers at the same wavelength (1.17 microns) using the same material system (InGaAs/AlGaAs).**
- **Both QDOT and QW indium compositions are tuned to have gain peak at 1.17 microns at T=300K.**
- **Assumption of no current spreading (1D) simulation, no temperature dependence in non-radiative carrier lifetime and Auger recombination.**

Gain Spectra



All four simulations are forced to lase at the same wavelength.
 N_s is the carrier surface density and N_{st} is threshold surface density.
 Remark: QDOT spectra less sensitive to temperature change.

Lasing behaviour



Comparison of lasing behavior at 300 and 400 K. All structures are forced to lase at 1.17 microns and temperature dependences in bandgap, optical gain, carrier concentration, and radiative recombination have been taken into account. All other quantities are assumed to be temperature independent for simplicity

Summary

- **An efficient QDOT model has been established for PICS3D/LASTIP/APSYS.**
- **QDOT model may be used for photo-detectors as well as for laser diodes/LED since gain/absorption model is implemented in the same way as QW model.**
- **Combination of microscopic and macroscopic modeling of QDOT offers both efficiency and accuracy.**
- **Simulated lasing behaviors for LD indicate substantial benefits for lasing threshold and temperature insensitivity.**